

新日本無線株式会社  
マイクロ波事業部

## NJR4266K 付属説明書

### 1. 内容物

評価キットの内容物は次の通りです。万が一、不足しているものがございましたら、購入先もしくはメーカー窓口にご連絡ください。

- 評価基板 …………… 1個
- USBケーブル …………… 1個
- 付属説明書（本紙）

マイクロ波センサモジュールNJR4266シリーズは付属しておりません。別途ご用意願います。

ご使用前には、本紙及び取扱説明書をよくお読みの上、正しく安全にお使いください。

取扱説明書とソフトウェアは弊社WEBサイトからダウンロード頂きたい、  
お願い申し上げます。

ダウンロードサイト：

<https://micro.njr.com/jpn/products/sensor/doppler/r4266.html>

#### 【お問い合わせ先のご案内】


新日本無線株式会社  
マイクロ波事業部  
第一営業部 営業課

e-mail: [mcsales@njr.co.jp](mailto:mcsales@njr.co.jp)


Web: <https://micro.njr.com>

### 2. 接続方法

- ① 評価基板に、センサモジュール(NJR4266シリーズ)を取り付けます。  
下図の通りJRCマークの向きを合わせて取り付けてください。  
センサの取り付け向きを間違えた場合、破損の要因となりますので、  
ご注意ください。



- ② 評価基板とパソコンのUSB端子に、USBケーブルを差し込み、つなぎます。



- ③ パソコンに保存したソフトウェアを起動する。  
ソフトウェアの使用詳細に関しては、取扱説明書を参照ください。

### 3. 注意事項

ご使用前には、取扱説明書に記載の注意事項をよくお読みの上、正しく安全にお使いください。

## Annex Instruction of NJR4266K

### 1. Contents

The contents of this evaluation kit are followings. If anything is missing, please contact the place of purchase or the manufacturer's office.

- Evaluation Board ..... 1 pc
- USB Cable ..... 1 pc
- Annex Instruction

Microwave sensor module (NJR4266 series) is not enclosed. Please prepare separately.

Before using, please read this manual and instruction manual carefully and use it properly and safely.

Please to download the GUI software from our website in below.

<https://micro.njr.com/eng/products/sensor/gui.html>

【Contact Point】  
**New Japan Radio Co., Ltd.**  
**Microwave Division**


e-mail: [mcsales@njr.co.jp](mailto:mcsales@njr.co.jp)  
Web: <https://micro.njr.com>

### 2. Connection Method


- Install Microwave sensor module (NJR4266 series) to evaluation board.

Please align the JRC marks as shown in the picture below.

If you misplace the install direction of the sensor, it will cause damage.



- Connect the evaluation board and the USB terminal of the personal computer with the included USB cable.



- Start the GUI software saved on the computer.